




KEY FEATURES

- effective drainage of moisture from the waterproof barrier through large drain and overflow holes
- firm restraint for the paving
- long-term durability and full corrosion resistance


TECHNICAL DATA

BODY	AW 6060 aluminium alloy
WEIGHT	approx. 1165 g/m (linear meter)
COATING SYSTEM	0.6 g/m ² conversion coating, and min. 60 µm polyester powder coating

INSTALLATION TOOLS

You will need the following tools: folding ruler, spirit level, knife, electric drill, hand-held mixer, steel plastering trowel, string line, pencil, spatula, metal handsaw or circular saw. Circular saw should be equipped with an aluminium cutting blade to cut without damaging the coating.

AUXILIARY COMPONENTS




BASE

The base must be sound, level and clean. Screeds should be of min. C20 strength and should cure for 28 days. A recess, 3 mm deep by 80 mm wide, should be formed around the floor perimeter to allow setting the drip edge flush with the screed top surface. This recess may be blocked out with blockout strip (supplied on request) in the case of new screed layers. In existing screeds the recess should be milled to the required depth and width (80 mm by 3 mm).

AMBIENT CONDITIONS DURING INSTALLATION

Ambient conditions should be as typically required for waterproofing and installation work.



COLOURS

Standard colours: RAL 7037 dusty grey, RAL 7024 graphite grey, RAL 8019 grey brown. Other colours from RAL Classic chart are available on request.

INSTALLATION

The edgings should be set on sealing slurry or flexible sealant and secured in place with plastick plugs. Follow the installation guide available at: <https://www.renoplast.pl/download>.

The SW edgings are designed for residential applications in private homes or apartment buildings. They are not intended for industrial environments or service/access stairs. Suitability for other applications depends on the design guidelines and/or code requirements. SW edgings should not be used as stair landing, terrace or balcony edge trims.

For this application use W30, W35 PLUS or other suitable trims. SW edgings are not suitable for stairs with goings longer than one paver length.



WITH STANDARD
BRACKET



WITH CONCEALED
BRACKET

INSTALLATION GUIDES

INSTALLATION GUIDELINES


Protect the paint coat from damage during installation. Reject any damaged components. Any dirt should be removed from the surfaces using water and non-abrasive cloth. Wet materials, such as sealing slurry or tile adhesive, should be removed from outer surfaces before drying. The manufacturer shall not be liable for any damage resulting from product misuse or using inadequate auxiliary materials or tools. All work must be in compliance with construction plans, product data sheet, relevant standards, good construction practice and safety requirements.

MAINTENANCE GUIDELINES


For cleaning use clean water with some detergent. Do not use highly acidic or high alkaline cleaners or surfactants, which may react with aluminium. Do not use organic solvents containing esters, ketones, aromatic compounds, glycol esters, chlorinated hydrocarbons, etc. After cleaning rinse the surfaces with cold clean water. In winter do not use salt or other de-icing chemicals. We recommend to check the condition of the relevant terrace, patio and balcony components every six months. Immediately remove any discovered defects.

DIMENSIONS


CROSS-SECTIONS:




SW STAIR EDGING




SW 90 MAXI STAIR EDGING
EXTERNAL CORNER




SWD 6 cm
RESTRAINT BRACKET




SWD 6 cm CONCEALED
RESTRAINT BRACKET




SWG 200 cm
RESTRAINT EDGE



INSTALLATION EXAMPLE



1. Restraint bracket/edge
2. SW stair edging
3. SMART pedestals
4. Waterproof barrier
5. 2 cm thick paver
6. Restraint edge
7. W20Z fascia coping
8. RENOPAD PRO adjustable pedestal



Notes:

Edition: 21.07.2026. This product brochure supersedes all previous editions. It gives recommendations for standard application conditions only, and thus shall not be used in place of installation drawings. Suitability of our products for particular conditions should be verified by the contractor. The actual product specifications may vary slightly due to allowable process or tool dimension changes. Any materials used in combination with Renoplast products must be obtained from reputable sources. Our liability for any omissions or inaccuracies of the data given in this brochure is limited to gross disinformation and/or negligence.

Renoplast

RENOPLAST Sp. z o.o.
phone: +48 697 635 580
office@renoplast.pl
www.renoplast.pl/en

