


W30R PLUS drip edge is part of BASIC W30R PLUS edging system used with pedestal flooring consisting of 2 cm porcelain pavers supported on SMART fixed-height pedestals placed on EPDM membrane waterproof barrier. W30R PLUS drip edges are designed to allow attachment of Renoplast R50 or RK65 gutter systems.



KEY FEATURES

- effective drainage of moisture from the waterproof barrier through large drain and overflow holes
- firm restraint for the paving
- long-term durability and full corrosion resistance
- compatible with Renoplast R50 or RK65 aluminium gutter systems


TECHNICAL DATA

BODY	AW 6060 aluminium alloy
WEIGHT	approx. 1320 g/m (linear meter)
COATING SYSTEM	0.6 - 1.2 g/m ² conversion coating, and min. 60 µm polyester powder coating

INSTALLATION TOOLS

You will need the following tools: folding ruler, spirit level, knife, electric drill, hand-held mixer, steel plastering trowel, string line, pencil, spatula, metal handsaw or circular saw. Circular saw should be equipped with an aluminium cutting blade to cut without damaging the coating.

AUXILIARY COMPONENTS




BASE

The base must be sound, level and clean. Screeds should be of min. C20 strength and should cure for 28 days. A recess, 3mm deep by 80 mm wide, should be formed around the floor perimeter to allow setting the drip edge flush with the screed top surface. This recess may be blocked out with blockout strip (supplied on request) in the case of new screed layers. In existing screeds the recess should be milled to the required depth and width (80 mm by 3 mm).

AMBIENT CONDITIONS DURING INSTALLATION

Ambient conditions should be as typically required for waterproofing and installation work.

W30R PLUS drip edge is part of BASIC W30R PLUS edging system used with pedestal flooring consisting of 2 cm porcelain pavers supported on SMART fixed-height pedestals placed on EPDM membrane waterproof barrier. W30R PLUS drip edges are designed to allow attachment of Renoplast R50 or RK65 gutter systems.



COLOURS

Standard colours: RAL 7037 dusty grey, RAL 7024 graphite grey, RAL 8019 grey brown. Other colours from RAL Classic chart are available on request.

INSTALLATION

The drip edges should be set on sealing slurry or flexible sealant and secured in place with plastic plugs. Follow the installation guide available at: <https://www.renoplast.pl/download>.

SEE PRODUCT →



INSTALLATION GUIDELINES


Protect the paint coat from damage during installation. Reject any damaged components. Any dirt should be removed from the surfaces using water and non-abrasive cloth. Wet materials, such as sealing slurry or tile adhesive should be removed from the outer surfaces before drying. The manufacturer shall not be liable for any damage resulting from product misuse or using inadequate auxiliary materials or tools. All work must be in compliance with construction plans, product data sheet, relevant standards, good construction practice and safety requirements.

MAINTENANCE GUIDELINES


For cleaning use clean water with some detergent. Do not use highly acidic or high alkaline cleaners or surfactants, which may react with aluminium. Do not use organic solvents containing esters, ketones, aromatic compounds, glycol esters, chlorinated hydrocarbons, etc. After cleaning rinse the surfaces with cold clean water. In winter do not use salt or other de-icing chemicals. We recommend to check the condition of the relevant terrace, patio and balcony components every six months. Immediately remove any discovered defects.

DIMENSIONS


CROSS-SECTION:




W30R PLUS DRIP EDGE




W30R PLUS 90
EXTERNAL CORNER




W30R PLUS 90
INTERNAL CORNER




W30R PLUS 135
EXTERNAL CORNER



W30R PLUS 135
INTERNAL CORNER




LW30/LW30R PLUS/
LW60/LW63 DRIP
EDGE CLIP




OPW30/OPW30R PLUS/
OPW60/OPW63 R+L
WALL PROTECTION
END CAPS


W30R PLUS drip edge is part of BASIC W30R PLUS edging system used with pedestal flooring consisting of 2 cm porcelain pavers supported on SMART fixed-height pedestals placed on EPDM membrane waterproof barrier. W30R PLUS drip edges are designed to allow attachment of Renoplast R50 or RK65 gutter systems.



INSTALLATION EXAMPLE



1. Structural slab
2. 1.5-2% sloping layer
3. EPDM, PVC or other appropriate waterproof sheet membrane
4. Paver
5. SMART pedestal
6. W30R PLUS drip edge
7. R50 round gutter



Uwagi:

Edition 4.05.2026. Publication of this Technical Data renders previous editions invalid. The above information refers only to general conditions of use of our products and cannot replace a technical design. When used in conditions other than recommended, the installer is obliged to test whether Renoplast products are suitable for application in the conditions. Information given in this technical information may differ slightly from the actual data, the difference may be due to permissible deviations or changes in production technology, changes in the dimensions of production tools. We recommend that materials from reliable manufacturers are used with Renoplast products. The liability of Renoplast Sp. z o.o. as to the scope and type of information provided is limited to claims in the case of gross negligence (intentional or negligent behaviour).

